

# BLAIR & OMAHA SUBS

EASTWARD  
page 1 of 2

REFERENCE ONLY  
For Learning Purposes  
Mistakes Guaranteed

8 SPEED CHANGE located MP xx.8


SIGNALS are for ALL MAINS & Controlled Sidings  
UNLESS Noted Different

1 # Detector Talker ( Always Talks )  
Located MP xxx.1

5 % Detector ( Talk On Defect Only )  
Located MP xxx.5


X PUBLIC at Grade Road Crossing

I Private at Grade Road Crossing




## BLAIR SUB

EAST




EAST




## OMAHA SUB

EAST




EAST



# BLAIR & OMAHA SUBS


WESTWARD  
page 2 of 2

REFERENCE ONLY  
For Learning Purposes  
Mistakes Guaranteed




See Tutorial at  
[www.FOGCHART.com](http://www.FOGCHART.com)

See TUTORIAL at  
[www.FOGCHART.com](http://www.FOGCHART.com)




## BLAIR SUB

WEST




WEST



## OMAHA SUB

WEST



WEST

