

# BLAIR & OMAHA SUBS

## EASTWARD page 1 of 2

REFERENCE ONLY  
For Learning Purposes  
Mistakes Guaranteed

8 SPEED CHANGE located MP xx.8


SIGNALS are for ALL MAINS & Controlled Sidings UNLESS Noted Different

1 # Detector Talker ( Always Talks ) Located MP xxx.1

5 % Detector ( Talk On Defect Only ) Located MP xxx.5



X PUBLIC at Grade Road Crossing

I Private at Grade Road Crossing




# BLAIR SUB

EAST




EAST




# OMAHA SUB

EAST




EAST



# BLAIR & OMAHA SUBS

WESTWARD  
page 2 of 2

REFERENCE ONLY  
For Learning Purposes  
Mistakes Guaranteed




See Tutorial at  
[www.FOGCHART.com](http://www.FOGCHART.com)


See TUTORIAL at  
[www.FOGCHART.com](http://www.FOGCHART.com)

## BLAIR SUB

WEST




WEST



## OMAHA SUB

WEST



WEST

