

# KEARNEY SUB ( Eastward )

Page 1 of 2



EMPLOYEE DRIVEN

- DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 0.0 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- ↑ PUBLIC ROAD CROSSING
- A AEI READER  
Located at MP xxx.3




Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.  
Grade is Averaged and Grade Number  
is Not Always shown for 4% or less

Report Corrections or Suggestions  
to:  
JKFREADMAN@COMCAST.NET  
WWW.FREADMAN.COM on the web

Throttle Modulation

Dynamic Braking

### NORTH PLATTE SUB



# KEARNEY SUB ( Eastward )

Page 2 of 2



EMPLOYEE DRIVEN



- DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- PRIVATE ROAD CROSSING
- PUBLIC ROAD CROSSING
- AEI READER  
Located at MP xxx.3

Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.


Grade is Averaged and Grade Number  
is Not Always shown for 4% or less

Report Corrections or Suggestions  
to:  
JKFREADMAN@COMCAST.NET  
WWW.FREADMAN.COM on the web

Throttle Modulation Dynamic Braking



PROTECT WHEN AGAINST CURRENT OF TRAFFIC



PROTECT WHEN AGAINST CURRENT OF TRAFFIC

PROTECT WHEN AGAINST CURRENT OF TRAFFIC

MY DATA IS LIMITED ON SIGNALS  
NEED HELP WITH GRAND ISLAND  
AND SIGNAL PLATE NUMBERS AT  
MP 239 FOR MAINS 2 and 3  
and MP 230 Westward  
THANKS *Jerry K. Freadman*

# KEARNEY SUB ( Westward )

Page 1 of 2



EMPLOYEE DRIVEN

- █ DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 00 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- ↑ PUBLIC ROAD CROSSING
- A AEI READER  
Located at MP xxx.3

Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.




Grade is Averaged and Grade Number  
is Not Always shown for 4% or less

Report Corrections or Suggestions  
to:  
JKFREADMAN@COMCAST.NET  
WWW.FREADMAN.COM on the web

Throttle Modulation

Dynamic Braking

MY DATA IS LIMITED ON SIGNALS  
 NEED HELP WITH GRAND ISLAND  
 AND SIGNAL PLATE NUMBERS AT  
 MP 239 FOR MAINS 2 and 3  
 and MP 230 Westward  
 THANKS *Jerry Kim Freadman*



# KEARNEY SUB ( Westward )

Page 2 of 2



EMPLOYEE DRIVEN

- 2 DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 00 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- ↑ PUBLIC ROAD CROSSING
- A AEI READER  
Located at MP xxx.3

Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

Grade is Averaged and Grade Number  
is Not Always shown for 4% or less

Report Corrections or Suggestions  
to:  
JKFREADMAN@COMCAST.NET  
WWW.FREADMAN.COM on the web

Throttle Modulation

Dynamic Braking

Automatic Braking

