

# ORIN SUB

( Eastward )

Page 1 of 4

Revised JULY 2009

For Learning Purposes ONLY  
Reference ONLY  
Mistakes GUARANTEED



EMPLOYEE DRIVEN

- 2 DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 5 5 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- X PUBLIC ROAD CROSSING
- A 3 AEI READER  
Located at MP xxx.3


Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

Grade is Averaged and Grade Number  
is Not always shown for .4% and lower


Report Corrections or Suggestions  
to:  
[WWW.FOGCHART.COM](http://WWW.FOGCHART.COM)

Throttle Modulation Dynamic Braking


**EAST**



**EAST**



**EAST**



# ORIN SUB

( Eastward )

Page 2 of 4

For Learning Purposes ONLY  
Reference ONLY  
Mistake GUARANTEED



EMPLOYEE DRIVEN

- DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- PRIVATE ROAD CROSSING
- PUBLIC ROAD CROSSING
- AEI READER  
Located at MP xxx.3

Revised JULY 2009


Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

Grade is Averaged and Grade Number is Not always shown for .4% and lower


Report Corrections or Suggestions to:  
[WWW.FOGCHART.COM](http://WWW.FOGCHART.COM)

**EAST**




Throttle Modulation Dynamic Braking



**EAST**



**EAST**



*Handwritten signature*

# ORIN SUB

( Westward )

Page 3 of 4

For Learning Purposes ONLY  
Reference ONLY  
Mistakes GUARANTEED



- 1 2 DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 0 5 5 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- ↑ PUBLIC ROAD CROSSING
- A 3 AEI READER  
Located at MP xxx.3


Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

Grade is Averaged and Grade Number  
is Not always shown for .4% and lower


Report Corrections or Suggestions  
to:  
[WWW.FOGCHART.COM](http://WWW.FOGCHART.COM)

WEST


Throttle Modulation Dynamic Braking



WEST



WEST



# ORIN SUB

( Westward )  
Page 4 of 4



EMPLOYEE DRIVEN

- 2 DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 0 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- X PUBLIC ROAD CROSSING
- A AEI READER  
Located at MP xxx.3


Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

Grade is Averaged and Grade Number is Not always shown for .4% and lower  
Report Corrections or Suggestions to:  
[WWW.FOGCHART.COM](http://WWW.FOGCHART.COM)


For Learning Purposes ONLY  
Reference ONLY  
Mistakes GUARANTEED

**WEST**


Throttle Modulation Dynamic Braking



**WEST**



**WEST**



*Handman*