






SIDNEY SUB 0235

EASTWARD Page 1 of 2

- 1 DETECTOR TALKER (ALWAYS TALKS)
Located at MP xxx.2
- 0 DETECTOR TALK ON DEFECT ONLY
Located at MP xxx.5
- x PRIVATE ROAD CROSSING
- x PUBLIC ROAD CROSSING
- A AEI READER







SIDNEY SUB 0235 (Eastward)

Page 2 of 2



Throttle Modulation
Dynamic Braking

- DETECTOR TALKER (ALWAYS TALKS)
Located at MP xxx.2
- DETECTOR TALK ON DEFECT ONLY
Located at MP xxx.5
- AEI READER
- PRIVATE ROAD CROSSING
- PUBLIC ROAD CROSSING



Handwritten signature: Jerry Kern

SIDNEY SUB 0235 (Westward)


Revised 01/08/2008








Throttle Modulation
Dynamic Braking

Report Corrections or Suggestions
WWW.FOGCHART.COM

- 2 DETECTOR TALKER (ALWAYS TALKS)
Located at MP xxx.2
- 0 5 DETECTOR TALK ON DEFECT ONLY
Located at MP xxx.5
- x PRIVATE ROAD CROSSING
- x PUBLIC ROAD CROSSING





SIDNEY SUB 0235
Westward Page 2 of 2

- 2 DETECTOR TALKER (ALWAYS TALKS)
Located at MP xxx.2
- 0 DETECTOR TALK ON DEFECT ONLY
Located at MP xxx.5
- 5 PRIVATE ROAD CROSSING
- x PUBLIC ROAD CROSSING
- A AEI READER

Revised 01/08/2008