

# SOUTH MORRILL 0214

(Eastward)

Page 1 of 2

Throttle Modulation Dynamic Braking

Revised 11/29/2007

Grade is Averaged and not always shown for .4% and less

- 2 DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 0 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- 5 PRIVATE ROAD CROSSING
- ↑ PUBLIC ROAD CROSSING





Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

For Learning Purposes ONLY  
Reference ONLY  
Mistakes GUARANTEED

Report Corrections or Suggestions  
to:  
[JKFREADMAN@COMCAST.NET](mailto:JKFREADMAN@COMCAST.NET)  
or  
[WWW.FOGCHART.COM](http://WWW.FOGCHART.COM) on the web



EMPLOYEE DRIVEN







# SOUTH MORRILL 0214

## (Eastward)

Page 2 of 2

Throttle Modulation Dynamic Braking

Revised 11/29/2007



Grade is Averaged and not always shown for .4% and less

- DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- ↑ PUBLIC ROAD CROSSING

Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

# SOUTH MORRILL 0214 ( Westward )

Page 1 of 2



Throttle Modulation Dynamic Braking

Revised 11/29/2007





Grade is Averaged and not always shown for .4% and less

- 2 DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 0 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- ↑ PRIVATE ROAD CROSSING
- ↑ PUBLIC ROAD CROSSING

For Learning Purposes ONLY  
Reference ONLY  
Mistakes GUARANTEED

Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

SIDNEY SUB  
NORTH PLATTE TERMINAL  
9 MILES



# SOUTH MORRILL 0214





## ( Westward )

Page 2 of 2

Throttle Modulation Dynamic Braking

Revised 11/29/2007

25 Trk 2  
40 Trk 1



Grade is Averaged and not always shown for .4% and less

- 0 DETECTOR TALKER ( ALWAYS TALKS )  
Located at MP xxx.2
- 0 DETECTOR TALK ON DEFECT ONLY  
Located at MP xxx.5
- | PRIVATE ROAD CROSSING
- X PUBLIC ROAD CROSSING

For Learning Purposes ONLY  
Reference ONLY  
Mistakes GUARANTEED

Report Corrections or Suggestions to:  
JKFREADMAN@COMCAST.NET  
or  
WWW.FOGCHART.COM on the web

Signals are for ALL MAINS unless so noted.  
Footage between signals is Rounded DOWN.

*Jerry K. Freadman*